

ASSEMBLY INSTRUCTIONS

BORROWDALE COMPANION SEAT & SINGLE CHAIR

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

PACKAGE CONTENTS

Single chair:

- 2 X End Frames
- 1 x Seat panel (4 slats)
- 1 x Back panel (5 slats)
- 70mm Coach Screws
- Cover caps.

Companion seats:

- 2 x single chair contents plus the following...
- 1 x Table Top
- 1 x Parasol Support

TOOLS REQUIRED

- 10mm socket or spanner
- Broom handle or similar and spirit level for companion seat



BORROWDALE COMPANION SEAT/SINGLE CHAIR

BORROWDALE COMPANION SEAT/SINGLE CHAIR

Step 1



Place the 2 seat end frames upright on a flat level surface and slot the seat panel into place as shown. (It is recommend you use an assistant for this step if possible). For the companion seat make sure each seat uses one each of the differing end frames to build a "mirror" pair.

Step 2



Align the seat panel flush with the front edge of the end frame as shown...

Step 3



...and working from underneath the seat secure in place using 2 of the coach screws. Repeat for the other side.

Step 4



Place the back panel into position as shown...

BORROWDALE COMPANION SEAT/SINGLE CHAIR

Step 5



...ensuring the angled batten tops are kept flush with the angled end frame uprights as shown above, and fix in place using 2 of the coach screws in each side..

Step 6



Cover any exposed screw heads using the cover caps provided. The Borrowdale chair is now complete. If you are constructing the companion seat, repeat steps 1-5 before commencing with step 7.

Step 7



Place the table top in position on the end frame (without an armrest) on one the completed chairs as shown above.

Step 8



Ensure its front edge finishes flush with the end frame as shown.

BORROWDALE COMPANION SEAT/SINGLE CHAIR

Step 9



Secure the table top in position using 2 of the coach screws.

Step 10



Now position the 2nd chair in place with its end frame front edge flush with the front edge of the table top as before and secure in place with 2 more of the coach screws.

Step 11



Place the parasol brace on the floor in between the seats with its longest edge toward the back of the seats



Guide a broom handle, parasol or similar length of dowel through the table top parasol hole and down into the hole in the parasol brace, then ensure the dowel is perfectly vertical using a spirit level.

BORROWDALE COMPANION SEAT/SINGLE CHAIR

Step 13



Now slide the parasol brace up the dowel...

Step 14



...until it meets the underside of the seat end frames.

Step 15



Check the positioning at both ends of the parasol brace to ensure it is identical at both ends, rotating the brace as necessary, before securing in place with the remaining coach screws.

Step 16



Cover any exposed screw heads using the using the cover caps provided. Your Borrowdale companion seat is now complete.

We hope that you found your product quick and easy to assemble.
However, if you require any further assistance or have any questions you can contact us by telephone on: **03333 448 121** or visit **www.gardenfurniture.direct**