

T: 03333 448 121

BORROWDALE GARDEN BENCH

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

PACKAGE CONTENTS

2 x End frames
1 x Seat (4 slats)
1 x Back Rest (5 slats)
70mm Coach screws
85mm Screws
Cover caps

TOOLS REQUIRED

10mm socket or spanner
Electric screwdriver with No2 Pozidrive bit
Or No2 Pozidrive Screwdriver



THE BORROWDALE GARDEN BENCH

BORROWDALE GARDEN BENCH

Step 1



Ensure that you have all of the correct parts as listed on the front page of these instructions, including any fixings.

Step 2



On a flat, level surface, slot the seat panel into one of the end frames as shown above.

Step 3



Now lift up the other side of the seat panel to locate the other end in place. (It is recommend you use an assistant for this step if possible).

Step 4



Align the seat panel flush with the front edge of the end frame as shown and secure in place using 2 of the 85mm screws. Repeat for the other end panel.

BORROWDALE GARDEN BENCH

Step 5



Working from underneath the seat panel use 2 coach screws to attach the seat panel to the end frame and then repeat for the other end panel.

Step 6



Locate the back rest panel in position with its battens between the end panel uprights and the upper edge of the batten flush with the top of the upright. Secure in place using 2 coach screws in each end. (It is recommend you use an assistant for this step if possible).

Step 7



Cover any exposed screws heads with the cover caps provided. Your Borrowdale bench is now complete.

We hope that you found your product quick and easy to assemble.
However, if you require any further assistance or have any questions you can contact us by telephone on: **03333 448 121** or visit **www.gardenfurniture.direct**