

T: 03333 448 121

HARRINGTON PICNIC BENCH

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

PACKAGE CONTENTS

- 1 x Table Top
- 2 x Seats
- 2 x Back Rests
- 2 x A-frames
- 2 x Braces
- 4 x L-shaped Back Rest Supports
- 40 x 70mm Coach Bolts
- 64 x Cover Caps

TOOLS REQUIRED

- 10mm socket or spanner



HARRINGTON PICNIC BENCH

HARRINGTON PICNIC BENCH

Step 1



Ensure that you have all of the correct parts as listed on the front page of these instructions, including any fixings.

Step 2



Lay the table top upside down on a clean, flat surface taking care not to damage it. Now line up one of the table A-frames centrally on the table top as shown in step 3.

Step 3



Place one of the table A-frames centrally against the fixing batten ensuring that the gap at the table edge is the same on both sides.

Step 4



Now, using 2 of the supplied coach screws and the pre drilled holes, secure the table A-frame to the fixing batten on the table top.

HARRINGTON PICNIC BENCH

Step 5



Place a cross brace in position as shown, ensuring that it is flush with the underside of the table A-frame and lined up centrally on the table and attach it to the A-frame with a coach screw.

Step 6



Make sure that the brace is still aligned centrally on the table and affix the other end to the table top with a coach screw as shown. Repeat steps 3 -6 to finish the table assembly and proceed to step 7.

Step 7



Locate the letter on each of the A-frames where the back rest supports will be located...

Step 8



...and find the corresponding back rest support. There will be an A, B,C and D.

HARRINGTON PICNIC BENCH

Step 9



Offer up the back rest support to the A-Frame as shown in the image and attach back rest support using 2 coach screws, first into the A-frame cross member...

Step 10



...and then 2 more into the A-Frame leg.

Step 11



Repeat steps 7 - 10 until you have attached all of the back rest supports as shown above.

Step 12



Place the seat panels on the A-Frames and ensure that the back of the seat panel lines up with the pencil mark on the top of the A-frame cross member.

HARRINGTON PICNIC BENCH

Step 13



Once lined up correctly, secure the seat in place using 2 coach screws.

Step 14



Repeats steps 12 -13 so that both seat panels are fixed in place as shown.

Step 15



Now offer up one the back rest panels and fix into place with coach screws at both ends of the bench, ensuring that the top of the back rest panel batten is flush with the top of the back rest support as shown in the image. Repeat for the other back panel.

Step 16



Finally, cover any exposed coach screw heads with the cover caps provided. Your Harrington picnic bench set is now complete.

We hope that you found your product quick and easy to assemble.
However, if you require any further assistance or have any questions you can contact us by telephone on: **03333 448 121** or visit **www.gardenfurniture.direct**